



Specific requirements with ear-impressions for our custom In-Ears

- 1 Please **ONLY** use impressions materials that build up a little pressure!
We cannot use any other materials for production-related reasons

For example:

Dreve: Otoform Ak, Otoform Ak X

Egger: A/II

- 2 Very Important:
- the **second bend** of the ear canal must be **completely** molded.
 - **Concha and Cymba** must be molded completely

During the process:

- 3
- closed mouth
 - relaxed face and jaw
 - do not use a biting block!
 - no chewing movements!

- 4 Please **flatten** the impression material with a foil.

If you have any questions or found something noteworthy during the process, please do not hesitate to contact us: +49 (0)221 80064334

Thank you very much for your cooperation!